

# NUC980 Ethernet Connection via NC-SI

Application Note for 32-bit NuMicro® Family

## Document Information

<b>Abstract</b>	This NUC980 Out-of-Band (OOB) module application supplementary document describes how the network interface of the NUC980 series microprocessor connects to the NC-SI (Network Controller Sideband Interface) of the host's network controller to simplify system design.
<b>Apply to</b>	NuMicro® NUC980 series.

*The information described in this document is the exclusive intellectual property of Nuvoton Technology Corporation and shall not be reproduced without permission from Nuvoton.*

*Nuvoton is providing this document only for reference purposes of NuMicro microcontroller and microprocessor based system design. Nuvoton assumes no responsibility for errors or omissions.*

*All data and specifications are subject to change without notice.*

For additional information or questions, please contact: Nuvoton Technology Corporation.

[www.nuvoton.com](http://www.nuvoton.com)

## Table of Contents

<b>1</b>	<b>OVERVIEW .....</b>	<b>3</b>
<b>2</b>	<b>HARDWARE AND SOFTWARE REQUIREMENTS.....</b>	<b>4</b>
2.1	Hardware Requirements .....	4
2.2	Software Requirements .....	4
<b>3</b>	<b>NUC980 AND NC-SI CONNECTION.....</b>	<b>5</b>
3.1	NC-SI Connection .....	5
3.2	Code Build.....	5
<b>4</b>	<b>CONCLUSION .....</b>	<b>9</b>
<b>5</b>	<b>APPENDIX .....</b>	<b>10</b>
5.1	Frequently Asked Questions (FAQ).....	10

## 1 Overview

With the independent external network connection of a NUC980 OOB module, when the host or device crashes, the NUC980 Out-of-Band (OOB) module can be the best remote control solution to monitor system status, and remotely turn off or reset the system.




Figure 1-1 System Architecture **without** NC-SI

The host for this type of application usually has an Ethernet network. Some Ethernet controllers support the NC-SI (Network Controller Sideband Interface<sup>\*1</sup>) standard defined by DMTF to enable the connection of a baseboard management controller (BMC) to network controller for out-of-band system management. Now the NUC980 series can act as a simplified BMC and its Ethernet network can connect to the NC-SI of the Ethernet controller on the host, so the host only needs one network jack. This saves board space and facilitates network cabling.




Figure 1-2 System Architecture **with** NC-SI

\*1 The [URL](#) of The Network Controller Sideband Interface (NC-SI) Specification.

## 2 Hardware and Software Requirements

For the network connection through NC-SI, the required items include:


### 2.1 Hardware Requirements

- A motherboard has an Ethernet Controller which supports NC-SI

For example, Intel i210 and i350 Ethernet controllers both support NC-SI. It would be better if its motherboard has a NC-SI connector.

- A NuMaker-RTU-NUC980 (also called Chili) board

This is the smallest NUC980 evaluation board used for NUC980 OOB solution. It has the RMII connector which is a good way for NC-SI connection. You can download the *NuMaker RTU NUC980 User Manual* from the [Nuvoton webpage](#).



- A Linux PC to build the software

Or a virtual machine running Linux. The Ubuntu Linux 20.04 LTS is recommended.

### 2.2 Software Requirements

- Buildroot for NUC980 with Linux v5.10

Buildroot is the tool to build a complete and bootable Linux environment for embedded system. For NC-SI, it supported in Linux v5 kernel. Please download the Buildroot for NUC980 with Linux v5.10 from the [github webpage](#).

- NuWriter

The firmware download or program tool for NUC980. It is in the tool directory of NUC980 BSP or can be downloaded from the [github webpage](#).

## 3 NUC980 and NC-SI Connection

### 3.1 NC-SI Connection

It is ideal to have an adapter board for the connection between NUC980 and network controller's NC-SI. Figure 3-1 is the reference circuit of the adapter board.




Figure 3-1 Reference Circuit of Adapter Board

In Figure 3-1, **P1** is a 2.54mm pitch dual row female header connector for NUC980 Chili board. **P2** is the connector for network controller's NC-SI. If host motherboard cannot provide a 50 MHz clock, an oscillator (**OSC1**) is required to generate the clock. The oscillator may not have enough power to drive both NUC980 RMII and Ethernet controller's NC-SI, so as to add the 2-channel output buffer (**U1**) to feed the clock to both sides.

### 3.2 Code Build

1. In Linux PC, get the Buildroot for NUC980.

```
$ git clone https://github.com/OpenNuvoton/MA35D1_Buildroot
$ cd MA35D1_Buildroot
$ make nuvoton_nuc980_chili_defconfig
```

2. Now, the Buildroot with Linux v5.10 has been configured for NUC980 Chili board. Then enable the support of NC-SI.

```
$ make linux-menuconfig
```

3. When the menu appears, select "Networking support" -> "Networking options", then find

the “NCSI interface support”.


```
.config - Linux/arm S.18.183 Kernel Configuration
> Networking support > Networking options

Networking options
Arrow keys navigate the menu. <Enter> selects submenus ---> (or empty
submenus ----). Highlighted letters are hotkeys. Pressing <Y>
includes, <N> excludes, <M> modularizes features. Press <Esc><Esc> to
exit, <?> for Help, </> for Search. Legend: [*] built-in [ ]

^(-)
< > NETLINK: socket monitoring interface
[ ] MultiProtocol Label Switching ----
< > Network Service Header (NSH) protocol ----
< > High-availability Seamless Redundancy (HSR & PRP)
[ ] Switch (and switch-ish) device support
[ ] L3 Master device support
< > Qualcomm IPC Router support
[ ] NCSI interface support
[ ] enable BPF Just In Time compiler
    Network testing --->

<Select>  < Exit >  < Help >  < Save >  < Load >
```

Press **space bar** or **Y** to enable to “**NCSI interface support**”, and also enable “**Get NCSI OEM MAC Address**” and “**Keep PHY Link up**”. If the network controller is Intel and host wants to connect to NUC980, enable the “**Allow traffic between host and sideband (Intel-specific)**”.



Then click “< **Save** >” to save the configuration.

4. The NUC980 has two EMACs, EMAC0 and EMAC1. The NUC980 Chili board uses EMAC1. Edit the dts file to enable NC-SI feature on the specified EMAC.

```
$ vi output/build/linux-custom/arch/arm/boot/dts/nuc980-chill.dts
```

Add the red box as shown below to EMAC1, then save it.

```
...
$ make
...
        status = "disabled";
    };
    emac1@b0022000 {
        use-ncsi;
        status = "okay";
    };
...
```

5. Build the firmware image for NUC980 Chili board.
6. After building is completed, please refer to *NUC980 NuWriter User Manual* or NUC980 OOB to program the firmware image to NUC980 Chili board.

Connect with a network cable, boot the NUC980 Chili board, and the Ethernet port should work well. The network connection goes through NC-SI to an outside server.



## 4 Conclusion

Using the NC-SI feature can save the board size and reduce the amount of network jacks to facilitate network cabling. This document provides steps to guide you how to use NC-SI, and provide frequently encountered questions and answers to save your development time. Please refer to Chapter 5 for Frequently Asked Questions (FAQ).

## 5 Appendix

### 5.1 Frequently Asked Questions (FAQ)

**1. Can NUC980 Ethernet work through NC-SI when system is turned off?**

The network controller on the motherboard still needs power to work. If NC-SI is used, make sure power is supplied to the network controller and NUC980.

**2. NC-SI seems not stable when jumping wire between NUC980 RMII and network controller.**

Because of high frequency signals, please shorten wires. If you use a 50 MHz oscillator, it is recommended to add a buffer. Please refer to the reference circuit of adapter board in this document.

**3. Can host and NUC980 communicate with each other via the network?**

For Intel Ethernet controller, please also enable the "Allow traffic between host and sideband (Intel-specific)" in Linux kernel configuration of NUC980 Buildroot.

**4. Host can connect to server but NUC980 still cannot connect to the server.**

Normally, if NC-SI is not used by default, the Ethernet controller (e.g. Intel i210) configuration is turned off. Please refer to Ethernet controller document to enable the NC-SI feature.

**5. When using 'ifconfig' to turn off Ethernet on NUC980, Ethernet cannot be turned on anymore.**

There is no Ethernet PHY for NUC980 when connecting to NC-SI, and no PHY response when Ethernet is turned on. Always keep NUC980 Ethernet enabled after booting.

**6. NUC980 has two EMAC. How to select one of the EMAC to connect to NC-SI?**

The dts file in "output/build/linux-custom/arm/boot/dts/" should be modified. Also add 'use-ncsi;' to the specified EMAC.

**7. Why RX-ERR pin is pull-down with 10 Kohm resistor directly?**

Since the sideband interface of Intel i210 network controller does not have RX-ERR wiring, the NUC980 RMII RX-ERR pin needs be pull-down to avoid the floating state in schematics design.

**8. The message in booting log appears: nuc980-eth0 b0022000.eth0: NCSI: No channel found to configure!**

Failed to configure pass-through mode. Please check RMII pins wiring between the NUC980 and network controller or related clock-buffer circuit.

## Revision History

Date	Revision	Description
2023.02.15	1.00	Initial version.

### Important Notice

Nuvoton Products are neither intended nor warranted for usage in systems or equipment, any malfunction or failure of which may cause loss of human life, bodily injury or severe property damage. Such applications are deemed, "Insecure Usage".

Insecure usage includes, but is not limited to: equipment for surgical implementation, atomic energy control instruments, airplane or spaceship instruments, the control or operation of dynamic, brake or safety systems designed for vehicular use, traffic signal instruments, all types of safety devices, and other applications intended to support or sustain life.

All Insecure Usage shall be made at customer's risk, and in the event that third parties lay claims to Nuvoton as a result of customer's Insecure Usage, customer shall indemnify the damages and liabilities thus incurred by Nuvoton.

---

*Please note that all data and specifications are subject to change without notice.  
All the trademarks of products and companies mentioned in this datasheet belong to their respective owners.*