

ARM® Cortex® - M

32-bit Microcontroller

# NuMaker-PFM-M487KM

## User Manual

### NuMicro® M480 Series

*The information described in this document is the exclusive intellectual property of Nuvoton Technology Corporation and shall not be reproduced without permission from Nuvoton.*

*Nuvoton is providing this document only for reference purposes of NuMicro microcontroller based system design. Nuvoton assumes no responsibility for errors or omissions.*

*All data and specifications are subject to change without notice.*

For additional information or questions, please contact: Nuvoton Technology Corporation.

[www.nuvoton.com](http://www.nuvoton.com)

**Table of Contents**

|        |   |    |
|--------|---|----|
| 1      | Overview.....                                     | 6  |
| 1.1    | M487 Series MCU Features .....                    | 6  |
| 1.2    | NuMaker-PFM-M487KM Board Features.....            | 7  |
| 2      | NuMaker-PFM-M487KM Board Overview.....            | 8  |
| 2.1    | Front View.....                                   | 8  |
| 2.2    | Rear View .....                                   | 9  |
| 2.3    | Arduino UNO Compatible Interface .....            | 10 |
| 2.4    | Pin Assignment for Extended Connectors .....      | 12 |
| 2.5    | System Configuration .....                        | 17 |
| 2.5.1  | 5V Power Source .....                             | 17 |
| 2.5.2  | 3.3V Power Source .....                           | 17 |
| 2.5.3  | USB Connectors .....                              | 18 |
| 2.5.4  | Ethernet Connectors .....                         | 18 |
| 2.5.5  | Arduino UNO Compatible Interface Connectors ..... | 18 |
| 2.5.6  | Extended Connectors .....                         | 18 |
| 2.5.7  | Phone Jack .....                                  | 18 |
| 2.5.8  | MicroSD Card Slot.....                            | 18 |
| 2.5.9  | Push-Buttons .....                                | 18 |
| 2.5.10 | LEDs .....  | 18 |
| 2.5.11 | Heartbeat Sensor Pads .....                       | 18 |
| 2.5.12 | Power Connectors .....                            | 18 |
| 2.6    | Audio.....  | 19 |
| 2.7    | Heartbeat Sensor .....                            | 20 |
| 2.8    | Nu-Link2-Me .....                                 | 22 |
| 2.9    | PCB Placement .....                               | 23 |
| 3      | Quick Start .....                                 | 24 |
| 3.1    | Toolchains Supporting .....                       | 24 |
| 3.2    | Nuvoton Nu-Link Driver Installation .....         | 24 |
| 3.3    | BSP Firmware Download.....                        | 26 |
| 3.4    | Hardware Setup .....                              | 26 |
| 3.5    | Find the Example Project.....                     | 28 |
| 3.6    | Execute the Project under Toolchains.....         | 28 |
| 3.6.1  | Keil MDK .....                                    | 28 |

|       |   |    |
|-------|---|----|
| 3.6.2 | IAR EWARM.....                          | 32 |
| 3.6.3 | NuEclipse .....                         | 33 |
| 4     | NuMaker-PFM-M487KM Schematics .....     | 34 |
| 4.1   | Nu-Link2-Me .....                       | 34 |
| 4.2   | M487KMCAN .....                         | 35 |
| 4.3   | Power Supply .....                      | 36 |
| 4.4   | Arduino UNO Compatible Interface .....  | 37 |
| 4.5   | MicroSD Card .....                      | 38 |
| 4.6   | USB 2.0 HS OTG and USB 1.1 FS OTG ..... | 39 |
| 4.7   | Ethernet .....                          | 40 |
| 4.8   | 24-bit Stereo Audio Codec .....         | 41 |
| 4.9   | Heartbeat Sensor .....                  | 42 |
| 5     | REVISION HISTORY .....                  | 43 |

## List of Figures

|   |    |
|---|----|
| Figure 1-1 NuMaker-PFM-M487KM Board .....                       | 6  |
| Figure 2-1 Front View of NuMaker-PFM-M487KM Board.....          | 8  |
| Figure 2-2 Rear View of NuMaker-PFM-M487KM Board .....          | 9  |
| Figure 2-3 Arduino UNO Compatible Interface .....               | 10 |
| Figure 2-4 NuMaker-PFM-M487KMCAN Extended Connectors .....      | 12 |
| Figure 2-5 3.5mm Phone Jack Diagram .....                       | 19 |
| Figure 2-6 Heartbeat Sensor Block Diagram .....                 | 20 |
| Figure 2-7 Front Placement .....                                | 23 |
| Figure 2-8 Rear Placement .....                                 | 23 |
| Figure 3-1 Nu-Link USB Driver Installation Setup.....           | 24 |
| Figure 3-2 Nu-Link USB Driver Installation .....                | 25 |
| Figure 3-3 Open VCOM Function .....                             | 26 |
| Figure 3-4 ICE USB Connector.....                               | 26 |
| Figure 3-5 Device Manger.....                                   | 27 |
| Figure 3-6 PuTTY Session Setting.....                           | 27 |
| Figure 3-7 Template Project Folder Path .....                   | 28 |
| Figure 3-8 Warning Message of “Device not found” .....          | 28 |
| Figure 3-9 Project File Migrate to Version 5 Format.....        | 29 |
| Figure 3-10 Debugger Setting in Options Window.....             | 29 |
| Figure 3-11 Programming Setting in Options Window.....          | 30 |
| Figure 3-12 Compile and Download the Project .....              | 30 |
| Figure 3-13 Keil MDK Debug Mode .....                           | 31 |
| Figure 3-14 Debug Message on Serial Port Terminal Windows ..... | 31 |
| Figure 3-15 IAR EWARM Window .....                              | 32 |
| Figure 3-16 Compile and Download the Project .....              | 32 |
| Figure 3-17 IAR EWARM Debug Mode .....                          | 33 |
| Figure 3-18 Debug Message on Serial Port Terminal Windows ..... | 33 |
| Figure 4-1 Nu-Link2-Me Circuit .....                            | 34 |
| Figure 4-2 M487KMCAN Pin Assignment.....                        | 35 |
| Figure 4-3 Power Circuit and Configurations .....               | 36 |
| Figure 4-4 Arduino UNO Compatible Interface .....               | 37 |
| Figure 4-5 MicroSD Card Circuit .....                           | 38 |
| Figure 4-6 USB HS OTG and FS OTG Circuits .....                 | 39 |
| Figure 4-7 Ethernet Circuit .....                               | 40 |
| Figure 4-8 Audio Codec Circuit .....                            | 41 |
| Figure 4-9 Heartbeat Sensor Circuits .....                      | 42 |

## ***List of Tables***

|  |    |
|--|----|
| Table 2-1 Arduino UNO Interface Mapping with M487KMCAN GPIO .....    | 11 |
| Table 2-2 Extended Connector JP6 Interface with M487KMCAN GPIO ..... | 13 |
| Table 2-3 Extended Connector JP8 Interface with M487KMCAN GPIO ..... | 14 |
| Table 2-4 Extended Connector JP7 Interface with M487KMCAN GPIO ..... | 15 |
| Table 2-5 Extended Connector JP9 Interface with M487KMCAN GPIO ..... | 16 |
| Table 2-6 NAU88L25 Mapping with NuMaker-PFM-M487KMCAN .....          | 19 |
| Table 2-7 Pin Usage of Heartbeat Sensor .....                        | 21 |
| Table 2-8 ICESW2 VCOM function.....                                  | 22 |

## 1 OVERVIEW

This user manual is aimed to give users a fast introduction to the use of NuMaker-PFM-M487KM board.

The NuMaker-PFM-M487KM consists of two parts, a M487KM platform and an on-board Nu-Link2-Me debugger and programmer. The NuMaker-PFM-M487KM allows users to quickly develop and easily program and debug application.

The NuMaker-PFM-M487KM offers M487KMCAN full pins extension connectors and Arduino UNO compatible extension connectors. It is an easy-to-develop platform for user to expand the functionality and build the applications. The NuMaker-PFM-M487KM also provides an ammeter connector, allows user to monitor the microcontroller's power consumption during development.

The Nu-Link2-Me is a debugger and programmer that supports on-line programming and debugging through SWD interface. The on-board 16 Mbit SPI Flash allows it able to off-line programming the target microcontroller. Nu-Link2-Me provides virtual COM port (VCOM) function to print out messages on PC. Nu-Link2-Me can be separated from NuMaker-PFM-M487KM, allowing user to use as a mass production programming tool.




Figure 1-1 NuMaker-PFM-M487KM Board

### 1.1 M487 Series MCU Features

- M487KMCAN in LQFP128 package
- ARM® Cortex®-M4 core running up to 192 MHz with DSP extensions and FPU (Floating Point Unit)
- 2560 Kbytes Flash
- 160 Kbytes SRAM
- External Bus Interface (EBI)
- GPIO
- Peripheral DMA (PDMA)
- Timer
- PWM and BPWM

- Quadrature Encoder Interface (QEI)
- WDT and WWDT
- RTC
- UART
- Smart Card (ISO-7816-3) Host Interface
- I<sup>2</sup>C
- SPI
- SPIM
- I<sup>2</sup>S
- Universal Serial Control Interface (USCI)
- USB 2.0 High-Speed OTG / Host / Device
- USB 1.1 Full-Speed OTG / Host / Device
- CAN 2.0
- Ethernet MAC
- SD Host
- Cryptographic Accelerator
- CRC
- ADC
- DAC
- Comparator

## 1.2 NuMaker-PFM-M487KM Board Features

- On-board Nu-Link2-Me debugger and programmer:
  - ◆ Debug through SWD interface
  - ◆ On-line/off-line programming
  - ◆ Virtual COM port function
- Arduino UNO compatible interface
- M487 extended interface connectors
- Audio codec (NAU88L25) with Microphone In and Headphone Out
- Ethernet for network application
- USB 2.0 High-Speed OTG / Host / Device
- USB 1.1 Full-Speed OTG / Host / Device
- External SPI Flash which can be regarded as ROM module
- MicroSD Card slot for T-Flash
- Three push-buttons: one is for reset and the other two are for user-defined
- Four LEDs: one is for power indication and the other two are for user-defined

## 2 NUMAKER-PFM-M487KM BOARD OVERVIEW

### 2.1 Front View

Figure 2-1 shows the main components and connectors from the front side of NuMaker-PFM-M487KM board.

The following lists components and connectors from the front view:

- Target Chip: M487KMCAN (U1)
- Audio: Audio Codec NAU88L25 (U8), Headphone (CN2)
- Arduino UNO compatible interface connectors (NU1, NU2, NU3, NU4 and NU5)
- M487 extended interface connectors (JP6, JP7, JP8 and JP9)
- USB: USB 2.0 High-Speed OTG connector (CON1) and USB 1.1 OTG connector (CON2)
- Ethernet Transceivers: IP101GR (U5)
- Push-buttons (SW2, SW3)
- LEDs (LEDR and LEDG)
- Nu-Link2-Me
  - ◆ VCOM Switch
  - ◆ ICE Chip: M48SSIDAE(ICEU1)
  - ◆ ICE USB Connector(ICEJ3)
  - ◆ ICE Status LED(ICES0,ICES1, ICES2, ICES3)
  - ◆ Off-line Program Button(ICESW1)




Figure 2-1 Front View of NuMaker-PFM-M487KM Board

## 2.2 Rear View

Figure 2-2 shows the main components and connectors from the rear side of NuMaker-PFM-M487KM board.

The following lists components and connectors from the rear view:

- MicroSD Card Slot: T-Flash slot (U9)
- Nu-Link2-Me
  - ◆ MCUVCC Power Switch (ICEJPR1)
  - ◆ ICEVCC Power Switch (ICEJPR2)




Figure 2-2 Rear View of NuMaker-PFM-M487KM Board

## 2.3 Arduino UNO Compatible Interface

Figure 2-3 shows the Arduino UNO compatible interface.




Figure 2-3 Arduino UNO Compatible Interface

Table 2-1 Arduino UNO Interface Mapping with M487KMCAN GPIO

| Header |       | NuMaker-PFM-M487KM        |                  | Header | NuMaker-PFM-M487KM        |                  |  |
|--------|-------|---------------------------|------------------|--------|---------------------------|------------------|--|
|        |       | Compatible to Arduino UNO | GPIO Pin of M487 |        | Compatible to Arduino UNO | GPIO Pin of M487 |  |
| NU1    | NU1.1 | NC                        | RESET            | NU4    | NU4.10                    | SCL              |  |
|        | NU1.2 | IOREF                     |                  |        | NU4.9                     | SDA              |  |
|        | NU1.3 | RESET                     |                  |        | NU4.8                     | VREF             |  |
|        | NU1.4 | 3VCC                      |                  |        | NU4.7                     | GND              |  |
|        | NU1.5 | 5VCC                      |                  |        | NU4.6                     | D13              |  |
|        | NU1.6 | GND                       |                  |        | NU4.5                     | D12              |  |
|        | NU1.7 | GND                       |                  |        | NU4.4                     | D11              |  |
|        | NU1.8 | VIN                       |                  |        | NU4.3                     | D10              |  |
| NU2    | NU2.1 | A0                        | PB.6             | NU3    | NU4.2                     | D9               |  |
|        | NU2.2 | A1                        | PB.7             |        | NU4.1                     | D8               |  |
|        | NU2.3 | A2                        | PB.8             |        | NU3.8                     | D7               |  |
|        | NU2.4 | A3                        | PB.9             |        | NU3.7                     | D6               |  |
|        | NU2.5 | A4                        | PB.0             |        | NU3.6                     | D5               |  |
|        | NU2.6 | A5                        | PB.1             |        | NU3.5                     | D4               |  |
|        |       |                           |                  |        | NU3.4                     | D3               |  |
|        |       |                           |                  |        | NU3.3                     | D2               |  |
|        |       |                           |                  |        | NU3.2                     | D1               |  |
|        |       |                           |                  |        | NU3.1                     | D0               |  |
|        |       |                           |                  |        |                           |                  |  |

| Header |       | NuMaker-PFM-M487KM        |                  | Header | NuMaker-PFM-M487KM        |                  |
|--------|-------|---------------------------|------------------|--------|---------------------------|------------------|
|        |       | Compatible to Arduino UNO | GPIO Pin of M487 |        | Compatible to Arduino UNO | GPIO Pin of M487 |
| NU5    | NU5.1 | MISO                      | PG.4             | NU5    | NU5.2                     | VCC              |
|        | NU5.3 | CLK                       | PA.10            |        | NU5.4                     | MOSI             |
|        | NU5.5 | NC                        | -                |        | NU5.6                     | GND              |
|        | NU5.7 | SS                        | PA.11            |        | NU5.8                     | NC               |

## 2.4 Pin Assignment for Extended Connectors

The NuMaker-PFM-M487KM provides the M487KMCAN target chip onboard and extended connectors (JP6, JP7, JP8 and JP9) for LQFP128-pin. The Figure 2-4 shows the NuMaker-PFM-M487KMCAN extended connectors.




Figure 2-4 NuMaker-PFM-M487KMCAN Extended Connectors

Table 2-2 Extended Connector JP6 Interface with M487KMCAN GPIO

| Header |        | NuMaker-PFM-M487KM |           | Header |        | NuMaker-PFM-M487KM |           |
|--------|--------|--------------------|-----------|--------|--------|--------------------|-----------|
|        |        | Pin No.            | Function  |        |        | Pin No             | Function  |
| JP6    | JP6.1  | 1                  | PB.5      | JP6    | JP6.2  | 2                  | PB.4      |
|        | JP6.3  | 3                  | PB.3      |        | JP6.4  | 4                  | OPA0_O    |
|        | JP6.5  | 5                  | PC.12     |        | JP6.6  | 6                  | PC.11     |
|        | JP6.7  | 7                  | PC.10     |        | JP6.8  | 8                  | PC.9      |
|        | JP6.9  | 9                  | OPA0_N    |        | JP6.10 | 10                 | OPA0_P    |
|        | JP6.11 | 11                 | GND       |        | JP6.12 | 12                 | 3VCC      |
|        | JP6.13 | 13                 | PA.11     |        | JP6.14 | 14                 | OPA1_O    |
|        | JP6.15 | 15                 | OPA1_N    |        | JP6.16 | 16                 | OPA1_P    |
|        | JP6.17 | 17                 | JKDET     |        | JP6.18 | 18                 | OPA2_O    |
|        | JP6.19 | 19                 | OPA2_N    |        | JP6.20 | 20                 | OPA2_P    |
|        | JP6.21 | 21                 | PG.2      |        | JP6.22 | 22                 | PG.3      |
|        | JP6.23 | 23                 | PG.4      |        | JP6.24 | 24                 | SW3       |
|        | JP6.25 | 25                 | I2S0_BCLK |        | JP6.26 | 26                 | I2S0_MCLK |
|        | JP6.27 | 27                 | I2S0_DI   |        | JP6.28 | 28                 | I2S0_DO   |
|        | JP6.29 | 29                 | I2S0_LRCK |        | JP6.30 | 30                 | 3VCC      |
|        | JP6.31 | 31                 | XT32_IN   |        | JP6.32 | 32                 | XT32_OUT  |

Table 2-3 Extended Connector JP8 Interface with M487KMCAN GPIO

| Header |        | NuMaker-PFM-M487KM |             | Header |        | NuMaker-PFM-M487KM |           |
|--------|--------|--------------------|-------------|--------|--------|--------------------|-----------|
|        |        | Pin No.            | Function    |        |        | Pin No             | Function  |
| JP7    | JP7.1  | 33                 | LED_R       | JP7    | JP7.2  | 34                 | LED_G     |
|        | JP7.3  | 35                 | PH.6        |        | JP7.4  | 36                 | PH.7      |
|        | JP7.5  | 37                 | XT1_IN      |        | JP7.6  | 38                 | XT1_OUT   |
|        | JP7.7  | 39                 | GND         |        | JP7.8  | 40                 | 3VCC      |
|        | JP7.9  | 41                 | EMAC_MDC    |        | JP7.10 | 42                 | EMAC_MDIO |
|        | JP7.11 | 43                 | EMAC_TXD0   |        | JP7.12 | 44                 | EMAC_RXD1 |
|        | JP7.13 | 45                 | EMAC_TXEN   |        | JP7.14 | 46                 | JKEN#     |
|        | JP7.15 | 47                 | EMAC_REFCLK |        | JP7.16 | 48                 | EMAC_RXD0 |
|        | JP7.17 | 49                 | EMCAC_RXD1  |        | JP7.18 | 50                 | EMAC_RXDV |
|        | JP7.19 | 51                 | EMAC_RXERR  |        | JP7.20 | 52                 | GND       |
|        | JP7.21 | 53                 | 3VCC        |        | JP7.22 | 54                 | LDO_CAP   |
|        | JP7.23 | 55                 | SD1_CMD     |        | JP7.24 | 56                 | PA.4      |
|        | JP7.25 | 57                 | PA.3        |        | JP7.26 | 58                 | PA.2      |
|        | JP7.27 | 59                 | PA.1        |        | JP7.28 | 60                 | PA.0      |
|        | JP7.29 | 61                 | VDDIO       |        | JP7.30 | 62                 | SD1_nCD   |
|        | JP7.31 | 63                 | PE.15       |        | JP7.32 | 64                 | nRESET    |

Table 2-4 Extended Connector JP7 Interface with M487KMCAN GPIO

| Header |        | NuMaker-PFM-M487KM |                 | Header |        | NuMaker-PFM-M487KM |             |
|--------|--------|--------------------|-----------------|--------|--------|--------------------|-------------|
|        |        | Pin No.            | Function        |        |        | Pin No.            | Function    |
| JP8    | JP8.1  | 65                 | ICEDAT          | JP8    | JP8.2  | 66                 | ICECLK      |
|        | JP8.3  | 67                 | I2C2_SCL        |        | JP8.4  | 68                 | I2C2_SDA    |
|        | JP8.5  | 69                 | I2C1_SCL        |        | JP8.6  | 70                 | I2C1_SDA    |
|        | JP8.7  | 71                 | PC.3            |        | JP8.8  | 72                 | PC.2        |
|        | JP8.9  | 73                 | PC.1            |        | JP8.10 | 74                 | PC.0        |
|        | JP8.11 | 75                 | GND             |        | JP8.12 | 76                 | 3VCC        |
|        | JP8.13 | 77                 | SD1_DAT3        |        | JP8.14 | 78                 | SD1_DAT2    |
|        | JP8.15 | 79                 | NC              |        | JP8.16 | 80                 | SD1_DAT0    |
|        | JP8.17 | 81                 | NC              |        | JP8.18 | 82                 | SD1_CLK     |
|        | JP8.19 | 83                 | SW2             |        | JP8.20 | 84                 | PD.13       |
|        | JP8.21 | 85                 | USB_VBUS        |        | JP8.22 | 86                 | USB_D-      |
|        | JP8.23 | 87                 | USB_D+          |        | JP8.24 | 88                 | USB_ID      |
|        | JP8.25 | 89                 | HSUSB_VRES      |        | JP8.26 | 90                 | HSUSB_VDD33 |
|        | JP8.27 | 91                 | HSUSB_VBUS      |        | JP8.28 | 92                 | HSUSB_D-    |
|        | JP8.29 | 93                 | HSUSB_VSS       |        | JP8.30 | 94                 | HSUSB_D+    |
|        | JP8.31 | 95                 | HSUSB_VDD12_CAP |        | JP8.32 | 96                 | HSUSB_ID    |

Table 2-5 Extended Connector JP9 Interface with M487KMCAN GPIO

| Header |        | NuMaker-PFM-M487KM |               | Header |        | NuMaker-PFM-M487KM |               |
|--------|--------|--------------------|---------------|--------|--------|--------------------|---------------|
|        |        | Pin No.            | Pin Name      |        |        | Pin No             | Pin Name      |
| JP9    | JP9.1  | 97                 | NC            | JP9    | JP9.2  | 98                 | NC            |
|        | JP9.3  | 99                 | PE.5          |        | JP9.4  | 100                | NC            |
|        | JP9.5  | 101                | PE.3          |        | JP9.6  | 102                | NC            |
|        | JP9.7  | 103                | GND           |        | JP9.8  | 104                | 3VCC          |
|        | JP9.9  | 105                | PE.1          |        | JP9.10 | 106                | PE.0          |
|        | JP9.11 | 107                | PH.8          |        | JP9.12 | 108                | PH.9          |
|        | JP9.13 | 109                | PH.10         |        | JP9.14 | 110                | PH.11         |
|        | JP9.15 | 111                | PD.14         |        | JP9.16 | 112                | GND           |
|        | JP9.17 | 113                | LDO_CAP       |        | JP9.18 | 114                | 3VCC          |
|        | JP9.19 | 115                | USB_VBUS_ST   |        | JP9.20 | 116                | USB_VBUS_EN   |
|        | JP9.21 | 117                | EADC0_CH14    |        | JP9.22 | 118                | TXD           |
|        | JP9.23 | 119                | RXD           |        | JP9.24 | 120                | AVDD          |
|        | JP9.25 | 121                | VREF          |        | JP9.26 | 122                | ADAVSS        |
|        | JP9.27 | 123                | HSUSB_VBUS_ST |        | JP9.28 | 124                | HSUSB_VBUS_EN |
|        | JP9.29 | 125                | PB.9          |        | JP9.30 | 126                | PB.8          |
|        | JP9.31 | 127                | PB.7          |        | JP9.32 | 128                | PB.6          |

## 2.5 System Configuration

### 2.5.1 5V Power Source

- **ICEJ:** USB connector in Nu-Link-Me to program code and supplies 5V power from PC Host.
- **CON1:** USB 2.0 High-Speed OTG connector on NuMaker-PFM-M487KM board to supply 5V power from PC Host when this USB is a device that be decided by the ID pin of OTG cable and this ID pin is low.
- **CON2:** USB 1.1 OTG connector on NuMaker-PFM-M487KM board to supply 5V power from PC Host when this USB is a device that be decided by the ID pin of OTG cable and this ID pin is low.
- **NU1 pin5:** VDD5V voltage connector on NuMaker-PFM-M487KM board to supply 5V power from external power source.

| Power Source       | Connector | Comment  |
|--------------------|-----------|--|
| ICE_USB_VBUS       | ICEJ3     | ICEJ supplies the 5V power from PC Host.<br><b>Note:</b> L2 should be shorted 0ohm                     |
| HSUSB_VBUS         | CON1      | CON1 supplies the 5V power from PC Host.<br><b>Note:</b> L11 should be shorted 0ohm.                   |
| USB_VBUS           | CON2      | CON2 supplies the 5V power from PC Host.<br><b>Note:</b> L12 should be shorted 0ohm.                   |
| External 5V Source | NU1 pin5  | NU1 pin5 supplies the 5V power from external power source.<br><b>Note:</b> L10 should be shorted 0ohm. |

### 2.5.2 3.3V Power Source

- **ICEUP1:** The voltage regular converts the 5V source to 3.3V and supplies it to NuMaker-PFM-M487KM board.
- **U4:** The voltage regular converts the 5V source to 3.3V and supplies it to NuMaker-PFM-M487KM board.

| Voltage Regular | 5V Source    | Comment  |
|-----------------|--------------|--|
| ICEUP1          | ICE_USB_VBUS | ICEU1 convert ICE_USB_VBUS to 3.3V and supplies it to M487 platform board.<br><b>Note:</b> L4 should be shorted 0ohm |
| U4              | HSUSB_VBUS   | U4 convert HSUSB_VBUS to 3.3V and supplies it to M487 platform board.<br><b>Note:</b> L5 should be shorted 0ohm.     |
| U4              | USB_VBUS     | U4 convert USB_VBUS to 3.3V and supplies it to M487 platform board.<br><b>Note:</b> L5 should be shorted 0ohm.       |

### 2.5.3 USB Connectors

- **ICEJ3:** USB connector (ICE) in Nu-Link-Me that connects to a PC's USB Host port to program code and supply power.
- **CON1:** USB 2.0 High-Speed connector (OTG) on NuMaker-PFM-M487KM board for USB OTG application use.
- **CON2:** USB 1.1 connector (OTG) on NuMaker-PFM-M487KM board for USB OTG application use.

### 2.5.4 Ethernet Connectors

- **CN1:** Ethernet connector (RJ-45) on NuMaker-PFM-M487KM board for application use.

### 2.5.5 Arduino UNO Compatible Interface Connectors

- **NU1, NU2, NU3, NU4 and NU5:** Arduino UNO compatible pins on the NuMaker-PFM-M487KM board.

### 2.5.6 Extended Connectors

- **JP6, JP7, JP8 and JP9:** Extended connectors interface pins on the NuMaker-PFM-M487KM board.

### 2.5.7 Phone Jack

- **CN2:** Phone jack connector on NuMaker-PFM-M487KM for audio application use.

### 2.5.8 MicroSD Card Slot

- **U9:** MicroSD card slot for application use.

### 2.5.9 Push-Buttons

- **SW1:** Reset button to reset the target chip on NuMaker-PFM-M487KM board.
- **SW2, SW3:** Only for application use.

### 2.5.10 LEDs

- **POWER:** The power LED indicates that the NuMaker-PFM-M487KM board is powered.
- **I/O1, I/O2 and I/O3:** Only for application use.

### 2.5.11 Heartbeat Sensor Pads

- **Heartbeat L:** The heartbeat sensor pad on the left hand.
- **Heartbeat R:** The heartbeat sensor pad on the right hand.

### 2.5.12 Power Connectors

- **JP2, JP3:** 3VCC connectors on the NuMaker-PFM-M487KM board.
- **JP4, JP5, JP10 and JP11:** GND connectors on the NuMaker-PFM-M487KM board.

## 2.6 Audio

NuMaker-PFM-M487KM features a Nuvoton NAU88L25 audio codec which is an ultra-low power high performance audio codec designed for headphone or headset application. It includes one I<sup>2</sup>S/PCM interface, one high quality stereo DACs, one mono ADC, a Class G stereo headphone amplifier, and industry leading advanced headset features.

The NAU88L25 connects to the NuMaker-PFM-M487KM via I<sup>2</sup>C bus (M487 is I<sup>2</sup>C master) for control, the I<sup>2</sup>C address of NUA88L25 is 0x1A by default, and via I<sup>2</sup>S bus (M487 is I<sup>2</sup>S slave) for audio digital data. The Table 2-6 shows the pin mapping between NUC88L25 and M487KMCAN.

Table 2-6 NAU88L25 Mapping with NuMaker-PFM-M487KMCAN

| NuMaker-PFM-M487KM | NAU88L25 | Comment   |
|--------------------|----------|---|
| I2C2_SCL           | SCLK     | I <sup>2</sup> C clock output<br><b>Note:</b> The I <sup>2</sup> C address of NAU88L25 is 0x1A by default.      |
| I2C2_SDA           | SDIO     | I <sup>2</sup> C data input/output<br><b>Note:</b> The I <sup>2</sup> C address of NAU88L25 is 0x1A by default. |
| I2S0_BCLK          | BCLK     | I <sup>2</sup> S bit clock output from NAU88L25   |
| I2S0_MCLK          | MCLK     | I <sup>2</sup> S master clock output from M487  |
| I2S0_DI            | ADCOUT   | I <sup>2</sup> S data input to NAU88L25   |
| I2S0_DO            | DACIN    | I <sup>2</sup> S data output from M487  |
| I2S0_LRCK          | FS       | I <sup>2</sup> S left right channel clock output from NAU88L25  |
| PC.13              | JKDET    | To detect phone jack insertion and ejection   |
| PE.13              | JKEN#    | To control phone jack output  |

The 3.5mm phone jack CN2 is used to attach the headset with microphone, the Figure 2-5 shows the phone jack diagram.




Figure 2-5 3.5mm Phone Jack Diagram

## 2.7 Heartbeat Sensor

NuMaker-PFM-M487KM features an on-board heartbeat sensor, it can detect the tiny electrical signal between human's right and left hand during each heartbeat. The tiny electrical signal passes through three stages of operational amplifiers which are built in M487KMCAN to amplify the differential electrical signal and filter the noise of environment. The Figure 2-6 shows the heartbeat sensor block diagram.

- **Heartbeat R/L Sensor Pads**

The heartbeat sensor pads are used to detect the tiny electrical signal between human's right and left hand during each heartbeat.

- **OPA0 (Differential Amplifier and Filter)**

OPA0 is used to amplify the differential electrical signal between right and left sensor pads and filter the DC bias then passes it to OPA1.

- **OPA1 (Bypass Filter and Input Buffer)**

OPA1 is a bypass filter which is used to suppress 60Hz noise and pass the signal without the noise to OPA2.

- **OPA2 (Amplifier)**

OPA2 is used to amplify the signal comes from OPA1 then passes it to the ADC channel of M487KMCAN to convert the analog signal to the digital signal.




Figure 2-6 Heartbeat Sensor Block Diagram

The pins of heartbeat sensor are share with other function of NuMaker-PFM-M487KM, the Table 2-7 shows the usage of heartbeat sensor.

Table 2-7 Pin Usage of Heartbeat Sensor

| M487JIDAE | Heartbeat Sensor | Alternative Function | Comment  |
|-----------|------------------|----------------------|--|
| PB.2      | OPA0_O           | D0                   | Short R69 to use the heartbeat function, otherwise it will be D0 of UNO Interface.       |
| PB.1      | OPA0_N           | A5                   | Short R70 to use the heartbeat function, otherwise it will be A5 of UNO Interface.       |
| PB.0      | OPA0_P           | A4                   | Short R71 to use the heartbeat function, otherwise it will be A4 of UNO Interface.       |
| PA.10     | OPA1_O           | ICSP_CLK             | Short R72 to use the heartbeat function, otherwise it will be CLK of UNO ICSP Interface. |
| PA.9      | OPA1_N           | ICSP_MISO            | Short R73 to use the heartbeat function, otherwise it will be MISO of UNO Interface.     |
| PA.8      | OPA1_P           | ICSP_MOSI            | Short R74 to use the heartbeat function, otherwise it will be MOSI of UNO Interface.     |
| PD.12     | OPA2_O           | -                    | Short R75 to use the heartbeat function, otherwise it will be PD.12 of M487KMCAN.        |
| PD.11     | OPA2_N           | -                    | Short R76 to use the heartbeat function, otherwise it will be PD.11 of M487KMCAN.        |
| PD.10     | OPA2_P           | -                    | Short R77 to use the heartbeat function, otherwise it will be PD.10 of M487KMCAN.        |
| PB.12     | DAC0_OUT         | ICE_RXD              | Short R68 to use the heartbeat function, otherwise it will be ICE_RXD of M487KMCAN.      |
| PB.14     | EADC0_CH14       | -                    | Short R60 to use the heartbeat function, otherwise it will be PB.14 of M487KMCAN.        |

## 2.8 Nu-Link2-Me

The Nu-Link2-Me is a debugger and programmer that supports on-line programming and debugging through SWD interface. The on-board 16 Mbit SPI Flash allows it to off-line program the target microcontroller. Additionally, the Nu-Link2-Me provides virtual COM port (VCOM) function to print out messages on PC. Table 2-8 presents how to set the VCOM function by ICESW2.

| ICESW2                              |          |  |
|-------------------------------------|----------|--|
| Pin                                 | Function | Comment  |
| 1                                   | TXD      | <b>On:</b> Connect target chip PB.13 (UART0_TXD) to Nu-Link2-Me.<br><b>Off:</b> Disconnect target chip PB.13 (UART0_TXD) to Nu-Link2-Me. |
| 2                                   | RXD      | <b>On:</b> Connect target chip PB.12 (UART0_RXD) to Nu-Link2-Me.<br><b>Off:</b> Disconnect target chip PB.12 (UART0_RXD) to Nu-Link2-Me. |
| <b>Note:</b> Pin 3 and 4 is unused. |          |  |

Table 2-8 ICESW2 VCOM function

## 2.9 PCB Placement

Figure 2-7 and Figure 2-8 show the front and rear placement of NuMaker-PFM-M487KM board.




Figure 2-7 Front Placement




Figure 2-8 Rear Placement

### 3 QUICK START

#### 3.1 Toolchains Supporting

Install the preferred toolchain. Please make sure at least one of the toolchains has been installed.

- [KEIL MDK Nuvoton edition M0/M23](#)
- [IAR EWARM](#)
- [NuEclipse \(GCC\)\(Windows\)](#)
- [NuEclipse \(GCC\)\(Linux\)](#)

#### 3.2 Nuvoton Nu-Link Driver Installation

Download and install the latest Nuvoton Nu-Link Driver.

- Download and install [Nu-Link Keil Driver](#) when using Keil MDK.
- Download and install [Nu-Link IAR Driver](#) when using IAR EWARM.
- Skip this step when using NuEclipse.

Please install the Nu-Link USB Driver as well at the end of the installation. The installation is presented in Figure 3-1 and Figure 3-2.




Figure 3-1 Nu-Link USB Driver Installation Setup



Figure 3-2 Nu-Link USB Driver Installation

### 3.3 BSP Firmware Download

Download and unzip the M480 [Board Support Package \(BSP\)](#).

### 3.4 Hardware Setup

1. Open the virtual COM (VCOM) function by changing Nu-Link2-Me VCOM Switch No. 1 and 2 to ON.




Figure 3-3 Open VCOM Function

2. Connect the ICE USB connector shown in Figure 3-4 to the PC USB port through USB cable.




Figure 3-4 ICE USB Connector

3. Find the “Nuvoton Virtual COM Port” on the Device Manager as Figure 3-5.




Figure 3-5 Device Manger

4. Open a serial port terminal, PuTTY for example, to print out debug message. Set the speed to 115200. Figure 3-6 presents the PuTTY session setting.




Figure 3-6 PuTTY Session Setting

### 3.5 Find the Example Project

Use the “Template” project as an example. The project can be found under the BSP folder as shown in Figure 3-7.




Figure 3-7 Template Project Folder Path

### 3.6 Execute the Project under Toolchains

Open and execute the project under the toolchain. The section 3.6.1, 0, and 3.6.3 describe the steps of executing project in Keil MDK, IAR EWARM and NuEclipse, respectively.

#### 3.6.1 Keil MDK

This section provides steps to beginners on how to run a project by using Keil MDK.

1. Double click the “Template.uvproj” to open the project.

**Note:** If Figure 3-8 warning message jumps out, please migrate to version 5 formats as shown in Figure 3-9. The “.uvproj” filename extension will change to “.uvprojx”.




Figure 3-8 Warning Message of “Device not found”




Figure 3-9 Project File Migrate to Version 5 Format

2. Make sure the debugger is “Nuvoton Nu-Link Debugger” as shown in Figure 3-10 and Figure 3-11.

**Note:** If the dropdown menu in Figure 3-10 does not contain “Nuvoton Nu-Link Debugger” item, please rework section 3.2.




Figure 3-10 Debugger Setting in Options Window




Figure 3-11 Programming Setting in Options Window

3. Rebuild all target files. After successfully compile the project, download code to the flash memory. Click “Start/Stop Debug Section” button can enter debug mode.




Figure 3-12 Compile and Download the Project

4. Figure 3-13 shows the debug mode under Keil MDK. Click “Run” and the debug message will be printed out as shown in Figure 3-14. User can debug the project under debug mode by checking

source code, assembly language, peripherals' registers, and setting breakpoint, step run, value monitor, etc.




Figure 3-13 Keil MDK Debug Mode



Figure 3-14 Debug Message on Serial Port Terminal Windows

### 3.6.2 IAR EWARM

This section provides steps to beginners on how to run a project by using IAR EWARM.

1. Double click the “Template.eww” to open the project.
2. Make sure the toolbar contain “Nu-Link” item as shown in Figure 3-15.

**Note:** If the toolbar does not contain “Nu-Link” item, please rework section 3.2.




Figure 3-15 IAR EWARM Window

3. Make target file as presented in Figure 3-16. After successfully compile the project, download code to the flash memory and enter debug mode.




Figure 3-16 Compile and Download the Project

4. Figure 3-17 shows the debug mode under IAR EWARN. Click “Go” and the debug message will be printed out as shown in Figure 3-18. User can debug the project under debug mode by checking source code, assembly language, peripherals’ registers, and setting breakpoint, step run, value monitor, etc.




Figure 3-17 IAR EWARM Debug Mode




Figure 3-18 Debug Message on Serial Port Terminal Windows

### 3.6.3 NuEclipse

For more information about how to use NuEclipse, please refer to the NuEclipse User Manual.

## 4 NUMAKER-PFM-M487KM SCHEMATICS

## 4.1 Nu-Link2-Me

Figure 4-1 shows the Nu-Link2-Me circuit. The Nu-Link2-Me is a debugger and programmer that supports on-line programming and debugging through SWD interface.




Figure 4-1 Nu-Link2-Me Circuit

## 4.2 M487KMCAN

Figure 4-2 shows the pin assignment of the M487KMCAN.




Figure 4-2 M487KMCAN Pin Assignment

### 4.3 Power Supply

Figure 4-3 shows power configurations of NuMaker-PFM-M487KM board.




Figure 4-3 Power Circuit and Configurations

#### 4.4 Arduino UNO Compatible Interface

Figure 4-4 shows the Arduino UNO compatible interface of NU1, NU2, NU5, NU6 and NU7 connectors.




Figure 4-4 Arduino UNO Compatible Interface

#### 4.5 MicroSD Card

Figure 4-5 shows the MicroSD Card circuit on the NuMaker-PFM-M487KM board.





Figure 4-5 MicroSD Card Circuit

#### 4.6 USB 2.0 HS OTG and USB 1.1 FS OTG

Figure 4-6 shows the USB 2.0 HS OTG and USB 1.1 FS OTG circuits on the NuMaker-PFM-M487KM board.




Figure 4-6 USB HS OTG and FS OTG Circuits

## 4.7 Ethernet

Figure 4-7 shows the Ethernet interface for networking application on the NuMaker-PFM-M487KM board.




Figure 4-7 Ethernet Circuit

#### 4.8 24-bit Stereo Audio Codec

Figure 4-8 shows the audio codec application circuit based on NAU88L25 to simplify implementation of complete audio system solutions.




Figure 4-8 Audio Codec Circuit

## 4.9 Heartbeat Sensor

Figure 4-9 shows the heartbeat sensor application circuit on the NuMaker-PFM-M487KM board.




Figure 4-9 Heartbeat Sensor Circuits

## 5 REVISION HISTORY

| Date       | Revision | Description          |
|------------|----------|----------------------|
| 2020.04.30 | 1.00     | 1. Initially issued. |

### Important Notice

Nuvoton Products are neither intended nor warranted for usage in systems or equipment, any malfunction or failure of which may cause loss of human life, bodily injury or severe property damage. Such applications are deemed, "Insecure Usage".

Insecure usage includes, but is not limited to: equipment for surgical implementation, atomic energy control instruments, airplane or spaceship instruments, the control or operation of dynamic, brake or safety systems designed for vehicular use, traffic signal instruments, all types of safety devices, and other applications intended to support or sustain life.

All Insecure Usage shall be made at customer's risk, and in the event that third parties lay claims to Nuvoton as a result of customer's Insecure Usage, customer shall indemnify the damages and liabilities thus incurred by Nuvoton.

---

Please note that all data and specifications are subject to change without notice.  
All the trademarks of products and companies mentioned in this datasheet belong to their respective owners.