

NuMicro[®] Family
Arm[®] Cortex[®]-M23-based Microcontroller

NuMaker-M2A23SG
User Manual

Evaluation Board for NuMicro[®] M2A23 Series

The information described in this document is the exclusive intellectual property of Nuvoton Technology Corporation and shall not be reproduced without permission from Nuvoton.

Nuvoton is providing this document only for reference purposes of NuMicro microcontroller and microprocessor based system design. Nuvoton assumes no responsibility for errors or omissions.

All data and specifications are subject to change without notice.

For additional information or questions, please contact: Nuvoton Technology Corporation.

www.nuvoton.com

Table of Contents

1 OVERVIEW	7
2 FEATURES	8
3 HARDWARE CONFIGURATION	9
3.1 Front View.....	9
3.2 Rear View	11
3.3 Extension Connectors.....	12
3.3.1 Pin Assignment for Extension Connectors	12
3.3.2 Arduino UNO Compatible Extension Connectors	15
3.4 Power Supply Configuration	17
3.4.1 VIN Power Source	17
3.4.2 5V Power Sources.....	17
3.4.3 3.3V Power Sources	18
3.4.4 1.8V Power Sources	18
3.4.5 Power Connectors.....	18
3.4.6 USB Connectors	19
3.4.7 Power Switches	19
3.4.8 Power Supply Models	19
3.5 External Reference Voltage Connector.....	23
3.6 Ammeter Connector	23
3.7 Function Switches	24
3.8 CAN Mode Selection.....	24
3.9 LIN Mode Selection.....	25
3.10 Push Buttons	25
3.11 LEDs	26
3.12 Nu-Link2-Me	26
3.12.1 VCOM Switches.....	26
3.12.2 Status LEDs	27
4 QUICK START	28
4.1 Toolchains Supporting	28
4.2 Nuvoton Nu-Link Driver Installation	28
4.3 BSP Firmware Download	30
4.4 Hardware Setup.....	30
4.5 Find the Example Project	32
4.6 Execute the Project under Toolchains	32
4.6.1 Keil MDK.....	32

4.6.2 IAR EWARM.....36

4.6.3 NuEclipse.....38

5 NUMAKER-M2A23SG SCHEMATICS..... 44

5.1 Nu-Link2-Me..... 44

5.2 M2A23 Target Board 45

5.3 Extension Connectors..... 46

5.4 PCB Placement 47

6 REVISION HISTORY 48

List of Figures

Figure 1-1 NuMaker-M2A23SG Evaluation Board	7
Figure 3-1 Front View of NuMaker-M2A23SG	9
Figure 3-2 Rear View of NuMaker-M2A23SG	11
Figure 3-3 M2A23SG5AC Extension Connectors	12
Figure 3-4 Arduino UNO Compatible Extension Connectors	15
Figure 3-5 External Power Supply Sources on Nu-Link2-Me	19
Figure 3-6 External Power Supply Sources on M2A23 Target Board	20
Figure 3-7 Detach the Nu-Link2-Me from NuMaker-M2A23SG	21
Figure 3-8 Wiring between Ammeter Connector and Ammeter	23
Figure 3-9 Project Path of SYS_PowerDown_MinCurrent	23
Figure 3-10 Function Switches on NuMaker-M2A23SG	24
Figure 4-1 Nu-Link USB Driver Installation Setup	28
Figure 4-2 Nu-Link USB Driver Installation	29
Figure 4-3 Open VCOM Function	30
Figure 4-4 ICE USB Connector	30
Figure 4-5 Device Manager	31
Figure 4-6 PuTTY Session Setting	31
Figure 4-7 Template Project Folder Path	32
Figure 4-8 Warning Message of "Device not found"	32
Figure 4-9 Project File Migrate to Version 5 Format	33
Figure 4-10 Debugger Setting in Options Window	33
Figure 4-11 Programming Setting in Options Window	34
Figure 4-12 Compile and Download the Project	34
Figure 4-13 Keil MDK Debug Mode	35
Figure 4-14 Debug Message on Serial Port Terminal Windows	35
Figure 4-15 IAR EWARM Window	36
Figure 4-16 Compile and Download the Project	36
Figure 4-17 IAR EWARM Debug Mode	37
Figure 4-18 Debug Message on Serial Port Terminal Windows	37
Figure 4-19 Import the Project in NuEclipse	38
Figure 4-20 Import Projects Windows	38
Figure 4-21 Open Project Properties Window	39
Figure 4-22 Project Properties Settings	39
Figure 4-23 Build Project	40
Figure 4-24 Open Debug Configuration	40
Figure 4-25 Main Tab Configuration	41

Figure 4-26 Debugger Tab Configuration 41

Figure 4-27 Startup Tab Configuration 42

Figure 4-28 NuEclipse Debug Mode 43

Figure 4-29 Debug Message on Serial Port Terminal Windows..... 43

Figure 5-1 Nu-Link2-Me Circuit..... 44

Figure 5-2 M2A23 Target Board Circuit 45

Figure 5-3 Extension Connectors Circuit 46

Figure 5-4 Front Placement 47

Figure 5-5 Rear Placement..... 47

List of Tables

Table 3-1 Extension Connectors.....	12
Table 3-2 M2A23SG5AC Full-pin Extension Connectors and GPIO Function List	14
Table 3-3 Arduino UNO Extension Connectors and M2A23SG5AC Mapping GPIO List.....	16
Table 3-4 Vin Power Source	17
Table 3-5 5V Power Sources	17
Table 3-6 3.3V Power Sources	18
Table 3-7 1.8V Power Sources	18
Table 3-8 Power Connectors	18
Table 3-9 USB Connectors	19
Table 3-10 Power Switches	19
Table 3-11 Supply External Power through Nu-Link2-Me	20
Table 3-12 Supply External Power for M2A23 Target Board.....	22
Table 3-13 External Reference Voltage Connector	23
Table 3-14 Ammeter Connector.....	23
Table 3-15 Function Switches.....	24
Table 3-16 Operating Mode of CAN Transceiver.....	24
Table 3-17 Operating Mode of LIN Transceiver.....	25
Table 3-18 Push Buttons.....	25
Table 3-19 LEDs	26
Table 3-20 VCOM Function of Nu-Link2-Me.....	26
Table 3-21 Operation Status LED Patterns	27

1 OVERVIEW

The NuMaker-M2A23SG is an evaluation board for Nuvoton NuMicro M2A23SG5AC, M2A23SE5AC, M2A23SD5AC, M2A23LG5AC, M2A23LE5AC, M2A23LD5AC, M2A23YG5AC, M2A23YE5AC and M2A23YD5AC microcontrollers. The NuMaker-M2A23SG consists of two parts: an M2A23 target board and an on-board Nu-Link2-Me debugger and programmer. The NuMaker-M2A23SG is designed for project evaluation, prototype development and validation with power consumption monitoring function.

The M2A23 target board is based on NuMicro M2A23SG5AC. For the development flexibility, the M2A23 target board provides the extension connectors, the Arduino UNO compatible headers and the capability of adopting multiple power supplies. The M2A23 target board also provides CAN and LIN transceiver for relative function development. Furthermore, the Nuvoton-designed ammeter connector can measure the power consumption instantly, which is essential for the prototype evaluation.

In addition, there is an attached on-board debugger and programmer “Nu-Link2-Me”. The Nu-Link2-Me supports on-chip debugging, online and offline ICP programming via SWD interface. The Nu-Link2-Me supports virtual COM (VCOM) port for printing debug messages on PC. Besides, the programming status could be shown on the built-in LEDs. Lastly, the Nu-Link2-Me could be detached from the evaluation board and become a stand-alone mass production programmer.




Figure 1-1 NuMaker-M2A23SG Evaluation Board

2 FEATURES

- NuMicro M2A23SG5AC used as main microcontroller with function compatible with:
 - M2A23SG5AC
 - M2A23SE5AC
 - M2A23SD5AC
 - M2A23LG5AC
 - M2A23LE5AC
 - M2A23LD5AC
 - M2A23YG5AC
 - M2A23YE5AC
 - M2A23YD5AC
- M2A23SG5AC full pins extension connectors
- Arduino UNO compatible extension connectors
- Ammeter connector for measuring the microcontroller's power consumption
- Flexible board power supply:
 - External V_{DD} power connector
 - Arduino UNO compatible extension connector V_{in}
 - LIN bus connector JP8_5VCC
 - USB power connector on M2A23 target board
 - ICE USB connector on Nu-Link2-Me
- On-board CAN transceiver and bus connector
- On-board LIN transceiver and bus connector
- On-board Nu-Link2-Me debugger and programmer:
 - Debug through SWD interface
 - Online/offline programming
 - Virtual COM port function

3 HARDWARE CONFIGURATION

3.1 Front View




Figure 3-1 Front View of NuMaker-M2A23SG

Figure 3-1 shows the main components and connectors from the front side of NuMaker-M2A23SG. The following lists components and connectors from the front view:

- Target chip: M2A23SG5AC (U1)
- USB PWR Connector (J3)
- Arduino UNO Compatible Extension Connectors (NU1, NU2, NU3, NU4)
- M2A23SG5AC Extension Connectors (JP3, JP4, JP5 and JP6)
- External V_{DD} Power Connector (JP1)
- External V_{SS} Power Connector (JP2)
- External V_{REF} Connector (VREF1)
- V_{DD} Switch (SW2)
- Ammeter Connector (AMMETER)
- Reset Button (SW1)
- Power LED and PF14 LED (LEDG1 and LEDR1)
- On-board CAN Transceiver (U3)
- CAN Bus Connector (JP7 and CAN0)
- CAN Function Switch (SW3)
 - ◆ Enable PC.4 and PC.5 to CAN transceiver
 - ◆ Enable PC.3 to control CAN Mode
- On-board LIN Transceiver (U4)
- LIN Bus Connector (JP8)
- LIN Function Switch (SW4)
 - ◆ Enable PA.6 and P7.7 to LIN transceiver
 - ◆ Enable PD.15 to control LIN mode

- Nu-Link2-Me
 - VCOM Switch
 - ICE Chip: M48SSIDAE (ICEU1)
 - ICE USB Connector (ICEJ2)
 - ICE Status LED (ICES0, ICES1, ICES2, ICES3)
 - Off-line Program Button (ICESW1)

3.2 Rear View

Figure 3-2 shows the main components and connectors from the rear side of NuMaker-M2A23SG.

The following lists components and connectors from the rear view:

- Nu-Link2-Me
 - MCUVCC Power Switch (ICEJPR1)
 - ICEVCC Power Switch (ICEJPR2)




Figure 3-2 Rear View of NuMaker-M2A23SG

3.3 Extension Connectors

Table 3-1 presents the extension connectors.

Connector	Description
JP3, JP4, JP5 and JP6	Full pins extension connectors on the NuMaker-M2A23SG.
NU1, NU2, NU3 and NU4	Arduino UNO compatible pins on the NuMaker-M2A23SG.

Table 3-1 Extension Connectors

3.3.1 Pin Assignment for Extension Connectors

The NuMaker-M2A23SG provides the M2A23SG5AC onboard and extension connectors (JP3, JP4, JP5 and JP6). Figure 3-3 shows the M2A23SG5AC extension connectors.




Figure 3-3 M2A23SG5AC Extension Connectors

Header			M2A23SG5AC	
			Pin No.	Function
JP3	JP3.1	JP3.2	1	PB.6 / ADC0_CH6 / UART1_RXD / USCI1_DAT1 / CANFD1_RXD / CANFD0_TXL / ACMP1_O / INT4
	JP3.3	JP3.4	2	PB.5 / ADC0_CH5 / ACMP1_N / I2C0_SCL / USCI1_CTL0 / CANFD0_TXD / CANFD0_TXH / PWM0_CH0 / TM0 / INT0
	JP3.5	JP3.6	3	PB.4 / ADC0_CH4 / ACMP1_P1 / I2C0_SDA / USCI1_CTL1 / CANFD0_RXD / PWM0_CH1 / TM1 / INT1
	JP3.7	JP3.8	4	PB.3 / ADC0_CH3 / ACMP0_N / UART1_TXD / I2C0_SMBAL / USCI1_DAT1 / CANFD1_TXD / CANFD1_TXH / PWM0_CH2 / CANFD1_TXL / TM2 / INT2
	JP3.9	JP3.10	5	PB.2 / ADC0_CH2 / ACMP0_P1 / UART1_RXD / I2C0_SMBSUS / USCI1_DAT0 / CANFD1_RXD / PWM0_CH3 / TM3 / INT3
	JP3.11	JP3.12	6	PB.1 / ADC0_CH1 / USCI1_CLK / CANFD0_TXD / CANFD0_TXH / PWM0_CH4 / PWM0_BRAKE0
	JP3.13	JP3.14	7	PB.0 / ADC0_CH0 / USCI0_CTL0 / CANFD0_RXD / PWM0_CH5 / PWM0_BRAKE1 / CANFD0_TXL
	JP3.15	JP3.16	8	PA.11 / ACMP0_P0 / LLSI0_OUT / USCI0_CLK / BPWM0_CH0 / TM0_EXT
	JP3.17	JP3.18	9	PA.10 / ACMP1_P0 / LLSI1_OUT / USCI0_DAT0 / CANFD1_TXL / BPWM0_CH1 / TM1_EXT
	JP3.19	JP3.20	10	PA.9 / UART1_TXD / USCI0_DAT1 / CANFD1_TXD / CANFD1_TXH / BPWM0_CH2 / TM2_EXT
	JP3.21	JP3.22	11	PA.8 / UART1_RXD / USCI0_CTL1 / CANFD1_RXD / BPWM0_CH3 / TM3_EXT / INT4
	JP3.23	JP3.24	12	PF.6 / SPI0_MOSI / CLK0
	JP3.25	JP3.26	13	PF.14 / TM3 / CLK0
	JP3.27	JP3.28	14	PF.5 / X32_IN / LLSI0_OUT / PWM0_CH0 / BPWM0_CH4 / ADC0_ST
	JP3.29	JP3.30	15	PF.4 / X32_OUT / LLSI1_OUT / CANFD0_TXL / PWM0_CH1 / BPWM0_CH5
	JP3.31	JP3.32	16	PF.3 / UART0_TXD / XT1_IN / I2C0_SCL / CANFD0_TXD / CANFD0_TXH
JP5	JP5.1	JP5.2	17	PF.2 / UART0_RXD / XT1_OUT / I2C0_SDA / CANFD0_RXD
	JP5.3	JP5.4	18	PC.7 / UART0_nCTS / LLSI0_OUT / TM0 / INT3
	JP5.5	JP5.6	19	PC.6 / UART0_nRTS / LLSI1_OUT / TM1 / INT2
	JP5.7	JP5.8	20	PA.7 / UART0_TXD / ACMP0_WLAT / TM2 / INT1
	JP5.9	JP5.10	21	PA.6 / UART0_RXD / ACMP1_WLAT / TM3 / INT0
	JP5.11	JP5.12	22	V _{SS}
	JP5.13	JP5.14	23	V _{DD}
	JP5.15	JP5.16	24	PD.15 / CANFD0_TXL / TM3 / INT1
	JP5.17	JP5.18	25	PA.5 / UART0_nCTS / UART0_TXD / I2C0_SCL / PWM0_CH0 / BPWM0_CH5
	JP5.19	JP5.20	26	PA.4 / UART0_nRTS / UART0_RXD / I2C0_SDA / CANFD0_TXD / CANFD0_TXH / PWM0_CH1 / BPWM0_CH4 / CANFD1_TXL
	JP5.21	JP5.22	27	PA.3 / UART1_TXD / SPI0_SS / I2C0_SMBAL / CANFD0_RXD / PWM0_CH2 / BPWM0_CH3 / CLK0
	JP5.23	JP5.24	28	PA.2 / UART1_RXD / SPI0_CLK / I2C0_SMBSUS / CANFD1_RXD / PWM0_CH3 / BPWM0_CH2 / CANFD1_TXL
	JP5.25	JP5.26	29	PA.1 / UART1_nCTS / UART0_TXD / SPI0_MISO / LLSI0_OUT / CANFD1_TXD / CANFD1_TXH / PWM0_CH4 / BPWM0_CH1
	JP5.27	JP5.28	30	PA.0 / UART1_nRTS / UART0_RXD / SPI0_MOSI / LLSI1_OUT / CANFD1_RXD / PWM0_CH5 / BPWM0_CH0
	JP5.29	JP5.30	31	PF.15 / CANFD2_TXL / CLK0 / INT4
	JP5.31	JP5.32	32	nRESET
JP4	JP4.1	JP4.2	33	PF.0 / UART1_TXD / UART0_TXD / CANFD2_TXD / CANFD2_TXH / ICE_DAT

	JP4.3	JP4.4	34	PF.1 / UART1_RXD / UART0_RXD / CANFD2_RXD / ICE_CLK
	JP4.5	JP4.6	35	PC.5 / LLSI0_OUT / CANFD0_TXD
	JP4.7	JP4.8	36	PC.4 / LLSI1_OUT / CANFD0_RXD / CANFD1_RXD
	JP4.9	JP4.10	37	PC.3 / I2C0_SMBAL / CANFD1_TXD
	JP4.11	JP4.12	38	PC.2 / I2C0_SMBUS / CANFD2_TXL
	JP4.13	JP4.14	39	PC.1 / I2C0_SCL / CANFD2_TXD / CANFD2_TXH / ACMP0_O / ADC0_ST
	JP4.15	JP4.16	40	PC.0 / I2C0_SDA / USCI0_CTL0 / CANFD2_RXD / ACMP1_O
	JP4.17	JP4.18	41	PD.3 / UART0_TXD / SPI0_SS / USCI0_CTL1
	JP4.19	JP4.20	42	PD.2 / UART0_RXD / SPI0_CLK / USCI0_DAT1
	JP4.21	JP4.22	43	PD.1 / SPI0_MISO / USCI0_DAT0
	JP4.23	JP4.24	44	PD.0 / SPI0_MOSI / USCI0_CLK / CANFD1_TXL / TM2
	JP4.25	JP4.26	45	PA.12 / SPI0_SS / I2C0_SMBAL / CANFD1_RXD / CANFD1_TXH
	JP4.27	JP4.28	46	PA.13 / SPI0_CLK / I2C0_SMBUS / CANFD1_TXD / CANFD0_TXL
	JP4.29	JP4.30	47	PA.14 / UART0_TXD / SPI0_MISO / LLSI0_OUT / CANFD0_TXD / CANFD0_TXH / ACMP0_WLAT
	JP4.15	JP4.32	48	PA.15 / UART0_RXD / SPI0_MOSI / LLSI1_OUT / CANFD0_RXD / CANFD2_TXL / ACMP1_WLAT
JP6	JP6.1	JP6.2	49	V _{SS}
	JP6.3	JP6.4	50	LDO_CAP
	JP6.5	JP6.6	51	V _{DD}
	JP6.7	JP6.8	52	PC.14 / USCI0_CTL0 / CANFD0_TXL / TM1
	JP6.9	JP6.10	53	PB.15 / ADC0_CH15 / UART0_nCTS / SPI0_SS / LLSI0_OUT / USCI0_CTL1 / CANFD2_TXD / CANFD2_TXH / TM0_EXT
	JP6.11	JP6.12	54	PB.14 / ADC0_CH14 / UART0_nRTS / SPI0_CLK / LLSI1_OUT / USCI0_DAT1 / CANFD2_RXD / CANFD0_TXL / TM1_EXT / CLK0
	JP6.13	JP6.14	55	PB.13 / ADC0_CH13 / ACMP0_P3 / ACMP1_P3 / UART0_TXD / SPI0_MISO / I2C0_SCL / USCI0_DAT0 / CANFD0_TXD / CANFD0_TXH / TM2_EXT
	JP6.15	JP6.16	56	PB.12 / ADC0_CH12 / ACMP0_P2 / ACMP1_P2 / UART0_RXD / SPI0_MOSI / I2C0_SDA / USCI0_CLK / CANFD0_RXD / TM3_EXT
	JP6.17	JP6.18	57	AV _{DD}
	JP6.19	JP6.20	58	V _{REF}
	JP6.21	JP6.22	59	AV _{SS}
	JP6.23	JP6.24	60	PB.11 / ADC0_CH11 / UART0_nCTS / CANFD0_TXD / CANFD0_TXH
	JP6.25	JP6.26	61	PB.10 / ADC0_CH10 / UART0_nRTS / USCI1_CTL0 / CANFD0_RXD / CANFD2_TXL
	JP6.27	JP6.28	62	PB.9 / ADC0_CH9 / UART0_TXD / UART1_nCTS / USCI1_CTL1 / CANFD2_TXD / CANFD2_TXH
	JP6.29	JP6.30	63	PB.8 / ADC0_CH8 / UART0_RXD / UART1_nRTS / USCI1_CLK / CANFD2_RXD / CANFD1_TXL
	JP6.15	JP6.32	64	PB.7 / ADC0_CH7 / UART1_TXD / USCI1_DAT0 / CANFD1_TXD / CANFD1_TXH / ACMP0_O / INT5

Table 3-2 M2A23SG5AC Full-pin Extension Connectors and GPIO Function List

3.3.2 Arduino UNO Compatible Extension Connectors

Figure 3-4 shows the Arduino UNO compatible extension connectors.




Figure 3-4 Arduino UNO Compatible Extension Connectors

Header		NuMaker-M2A23SG		Header		NuMaker-M2A23SG	
		Compatible to Arduino UNO	GPIO Pin of M2A23SG5AC			Compatible to Arduino UNO	GPIO Pin of M2A23SG5AC
NU3	NU3.1	D0	PA.8	NU2	NU2.6	A5	PB.1
	NU3.2	D1	PA.9		NU2.5	A4	PB.2
	NU3.3	D2	PA.5		NU2.4	A3	PB.6
	NU3.4	D3	PA.4		NU2.3	A2	PB.7
	NU3.5	D4	PA.10		NU2.2	A1	PB.8
	NU3.6	D5	PA.11		NU2.1	A0	PB.9
	NU3.7	D6	PB.0	NU1	NU1.8	VIN	-
	NU3.8	D7	PB.3		NU1.7	VSS	V _{SS}
NU4	NU4.1	D8	PB.4		NU1.6	VSS	V _{SS}
	NU4.2	D9	PB.5		NU1.5	5V	-
	NU4.3	D10	PA.3		NU1.4	3V	-
	NU4.4	D11	PA.0		NU1.3	RST	nRESET
	NU4.5	D12	PA.1		NU1.2	IOREF	V _{DD}
	NU4.6	D13	PA.2		NU1.1	NC	-
	NU4.7	VSS	V _{SS}				
	NU4.8	VREF	V _{REF}				
	NU4.9	SDA	PC.0				
	NU4.10	SCL	PC.1				

Table 3-3 Arduino UNO Extension Connectors and M2A23SG5AC Mapping GPIO List

3.4 Power Supply Configuration

The NuMaker-M2A23SG is able to adopt multiple power supplies. External power sources include NU1 Vin (7V to 12V), V_{DD} (depending on the target chip operating voltage), LIN bus through connector JP8, and PC through USB connector. By using switches and voltage regulator, multiple power domains can be created on the NuMaker-M2A23SG.

3.4.1 VIN Power Source

Table 3-4 presents the Vin power source.

Connector	Net Name in Schematic	Description
NU1 pin8	NU1_VIN	Board external power source, with voltage range from 7V to 12V. The voltage regulator UP2 converts the NU1 pin8 input voltage to 5V and supplies it to NU1_5VCC.

Table 3-4 Vin Power Source

3.4.2 5V Power Sources

Table 3-5 presents the 5V power sources.

Connector	Net Name in Schematic	Description
ICEJ2	USB_HS_VBUS	ICE USB connector supplies 5V power from PC to M2A23 target board and Nu-Link2-Me.
J3	USB_VBUS	USB connector on NuMaker-M2A23SG supplies 5V power from PC to M2A23 target board and Nu-Link2-Me. Note: If Nu-Link2-Me is detached, user should use J3 or JP8 to provide power to CAN and LIN transceiver.
NU1 pin5	NU1_5VCC	ICEJ2, J3 or NU1 pin8 supplies 5V power to NU1 pin5. NU1 pin5 supplies 5V power to target chip or Arduino adapter board.
JP8	JP8_5VCC	JP8 on NuMaker-M2A23SG supplies 5V power from LIN bus to M2A23 platform and Nu-Link2-Me. Note: If Nu-Link2-Me is detached, user should use J3 or JP8 to provide power to CAN and LIN transceiver.

Table 3-5 5V Power Sources

3.4.3 3.3V Power Sources

Table 3-6 presents the 3.3V power sources.

Voltage Regulator	5V Source	Description
ICEUP1	USB_HS_VBUS	ICEUP1 converts USB_HS_VBUS to 3.3V and supplies 3.3V to M2A23 target board or ICE chip.
UP1	USB_VBUS	UP1 converts USB_VBUS to 3.3V and supplies 3.3V to M2A23 target board.
UP1	NU1_5VCC	UP1 converts NU1_5VCC to 3.3V and supplies 3.3V to M2A23 target board.
UP1	JP8_5VCC	UP1 converts JP8_5VCC to 3.3V and supplies 3.3V to M2A23 target board.

Table 3-6 3.3V Power Sources

3.4.4 1.8V Power Sources

Table 3-7 presents the 1.8V power source.

Voltage Regular	5V Source	Description
ICEUP2	USB_HS_VBUS	ICEUP2 converts USB_HS_VBUS to 1.8V and supplies 1.8V to M2A23 target board or ICE chip.

Table 3-7 1.8V Power Sources

3.4.5 Power Connectors

Table 3-8 presents the power connectors.

Connector	Description
JP1	V _{DD} connector on the NuMaker-M2A23SG.
JP2	V _{SS} connector on the NuMaker-M2A23SG.

Table 3-8 Power Connectors

3.4.6 USB Connectors

Table 3-9 presents the USB connectors.

Connector	Description
ICEJ2	ICE USB connector on Nu-Link2-Me for power supply, debugging and programming from PC.
J3	USB power connector on NuMaker-M2A23SG for power supply.

Table 3-9 USB Connectors

3.4.7 Power Switches

Table 3-10 presents the power switches.

Switch	Description
ICEJPR1	Configures the target chip operating voltage at 1.8V / 3.3V / 5V. Note: M2A23 operating voltage range is from 2.5V to 5.5V. Do not switch ICEJPR1 (MCUVCC) to 1.8V.
ICEJPR2	Configures the ICE chip operating voltage at 1.8V / 3.3V.
SW2	Configures the target chip operating voltage at 3.3V / 5V. Note: If user wants to switch SW2.1 (NU1 5VCC) to ON, user should short or solder a 0 Ω resistor to R12.

Table 3-10 Power Switches

3.4.8 Power Supply Models

3.4.8.1 External Power Supply through Nu-Link2-Me to Target Chip

The external power supply source on Nu-Link2-Me is shown in Figure 3-5.




Figure 3-5 External Power Supply Sources on Nu-Link2-Me

To use ICEJ2 as external power supply source with Nu-Link2-Me, please follow the steps below:

1. Solder the resistor on ICEJPR1 (MCUVCC) depending on the target chip operating voltage.
2. Solder the resistor on ICEJPR2 (ICEVCC) depending on the ICE chip operating voltage.
3. Switch the SW2 to OFF.
4. Connect the external power supply to ICEJ2.

Table 3-11 presents all power models when supplying external power through Nu-Link2-Me. The Nu-Link2-Me external power sources are highlighted in yellow.

Model	Target Chip Voltage	ICEJ2	ICEJPR1 (MCUVCC) Selection ^[1]	ICEJPR2 (ICEVCC) Selection ^[2]	ICE Chip Voltage	SW2 Selection	J3	Vin	JP1
1	3.3V	Connect to PC	3.3V (default)	3.3V (default)	3.3V	Off	-	-	3.3V output
2	5V	Connect to PC	5V	3.3V (default)	3.3V	Off	-	-	5V output

Note:

1. 0 Ω should be soldered between ICEJPR1's MCVCC and 3.3V / 5V.
2. 0 Ω should be soldered between ICEJPR2's ICEVCC and 1.8V / 3.3V.
3. -: Unused.

Table 3-11 Supply External Power through Nu-Link2-Me

3.4.8.2 External Power Supply through MA23SG Target Board to Target Chip

The external power supply sources on M2A23 target board are shown in Figure 3-6.




Figure 3-6 External Power Supply Sources on M2A23 Target Board

To use Vin, J3 or JP8 as external power supply source, please follow the steps below:

1. Switch the SW2 depending on the target chip operating voltage.
2. Remove the resistor on ICEJPR1 (MCUVCC).
3. Solder the resistor on ICEJPR2 (ICEVCC) depending on the ICE chip operating voltage.
4. Connect the external power supply to Vin, J3 or JP8.

To use JP1 as external power supply source, please follow the steps below:

1. Switch the SW2 to OFF.
2. Remove the resistor on ICEJPR1 (MCUVCC).
3. Solder the resistor on ICEJPR2 (ICEVCC) depending on the ICE chip operating voltage.

4. Connect ICEJ2 to PC.
5. Connect the external power supply to JP1.

To use Vin, J3 or JP8 as external power supply source with Nu-Link2-Me detached from NuMaker-M2A23SG, please follow the steps below:

1. Switch the SW2 depending on the target chip operating voltage.
2. Detach the Nu-Link2-Me from NuMaker-M2A23SG.
3. Connect the external power supply to Vin, J3 or JP8.

To use JP1 as external power supply source with Nu-Link2-Me detached from NuMaker-M2A23SG, please follow the steps below:

1. Switch the SW2 to OFF.
2. Detach the Nu-Link2-Me from NuMaker-M2A23SG.
3. Connect the external power supply to JP1.




Figure 3-7 Detach the Nu-Link2-Me from NuMaker-M2A23SG

Table 3-12 presents all power models when supplies external power through M2A23 target board. The M2A23 target board external power sources are highlighted in yellow.

Model	Target Chip Voltage	Vin ^[1]	J3 ^[1]	JP8 ^[1]	ICEJ2	SW2 Selection	JP1 ^[2]	ICEJPR1 (MCUVCC) Selection ^[3]	ICEJPR2 (ICEVCC) Selection ^[4]	ICE Chip Voltage ^[5]
3	3.3V	7V ~ 12V Input	-	-	-	NU1 3VCC	3.3V output	Remove resistor	3.3V	3.3V
4	3.3V	-	Connect to PC	-	-	NU1 3VCC	3.3V output	Remove resistor	3.3V	3.3V
5	3.3V	-	-	Connect to LIN bus	-	NU1 3VCC	3.3V output	Remove resistor	3.3V	3.3V
6	5V	7V ~ 12V Input	-	-	-	NU1 5VCC ^[6]	5V output	Remove resistor	3.3V	3.3V
7	5V	-	Connect to PC	-	-	NU1 5VCC ^[6]	5V output	Remove resistor	3.3V	3.3V
8	5V	-	-	Connect to LIN bus	-	NU1 5VCC ^[6]	5V output	Remove resistor	3.3V	3.3V
9	2.5V ~ 5.5V	-	-	-	Connect to PC	OFF	DC Input 2.5V ~ 5.5V	Remove resistor	1.8V / 3.3V	1.8V / 3.3V
10	2.5V ~ 5.5V	-	-	-	Nu-Link2-Me removed	OFF	DC Input 2.5V ~ 5.5V	-	-	-

Note:

1. The Vin input voltage will be converted by voltage regulator UP2 to 5V. Supplying external power to Vin, J3 or JP8 can provide 5V to NU1 pin5 (5V) and 3.3V to NU1 pin4 (3VCC).
2. JP1 external power input only provides voltage to target chip.
3. 0 Ω should be removed from ICEJPR1's MCVCC and 1.8V / 3.3V / 5V.
4. 0 Ω should be soldered between ICEJPR2's ICEVCC and 1.8V / 3.3V.
5. The ICE chip voltage should be close to the target chip voltage.
6. 0 Ω should be soldered to R12 or short R12.
7. -: Unused

Table 3-12 Supply External Power for M2A23 Target Board

3.5 External Reference Voltage Connector

Table 3-14 presents the external reference voltage connector.

Connector	Description
VREF1	Connector for user to connect to the external reference voltage pin of the target chip. User needs to remove the L5 ferrite bead.

Table 3-13 External Reference Voltage Connector

3.6 Ammeter Connector

User can refer to the sample code in M2A23 series BSP - SYS_PowerDown_MinCurrent and Figure 3-8 to measure the minimum current in Power-down mode. Figure 3-9 shows the path of the sample code, which has relative settings of entering Power-down mode.

Table 3-14 presents the ammeter connector.

Connector	Description
AMMETER	Connector for user to measure the target chip power consumption easily. User needs to remove the R16 resistor.

Table 3-14 Ammeter Connector




Figure 3-8 Wiring between Ammeter Connector and Ammeter

📁 M2A23_Series_BSP_CMSIS_V3.XX.XXX
📁 SampleCode
📁 StdDriver
📁 SYS_PowerDown_MinCurrent

Figure 3-9 Project Path of SYS_PowerDown_MinCurrent

3.7 Function Switches

Table 3-15 presents the function switches.

Component	Description
SW3	Switch both SW3.3 and SW3.4 to ON to enable PC.4 and PC.5 to CAN transceiver. Switch SW3.2 to ON to enable PC.3 to control CAN mode.
SW4	Switch both SW4.3 and SW4.4 to ON to enable PA.6 and PA.7 to LIN transceiver. Switch SW4.2 to ON to enable PD.15 to control LIN mode.

Table 3-15 Function Switches




Figure 3-10 Function Switches on NuMaker-M2A23SG

3.8 CAN Mode Selection

Table 3-16 presents all selection to control operating mode of CAN transceiver. The control sources are highlighted in yellow.

Model	CAN Operating Mode	R18	R17	PC.3	SW3.3	SW3.4	SW3.2
1	Disable	-	-	-	OFF	OFF	OFF
2	Normal	0Ω	-	-	ON	ON	OFF
3	Normal	-	0Ω	Low	ON	ON	ON
4	Silent	-	0Ω	High	ON	ON	ON
Note: -: Unused							

Table 3-16 Operating Mode of CAN Transceiver

3.9 LIN Mode Selection

Table 3-17 presents all selection to control operating mode of LIN transceiver. The control sources are highlighted in yellow.

Model	LIN Operating Mode	R21	MASTER	PD.15	SW4.3	SW4.4	SW4.2
1	Reset	-	-	-	OFF	OFF	OFF
2	Master Normal	0Ω	-	High	ON	ON	ON
3	Master Sleep	0Ω	-	Low	ON	ON	ON
4	Master Normal	-	0Ω	High	ON	ON	ON
5	Master Sleep	-	0Ω	Low	ON	ON	ON
6	Slave Normal	-	-	High	ON	ON	ON
7	Slave Sleep	-	-	Low	ON	ON	ON
Note: -: Unused							

Table 3-17 Operating Mode of LIN Transceiver

3.10 Push Buttons

Table 3-18 presents the push buttons.

Component	Description
ICESW1	Offline program button to start offline ICP programming the target chip.
SW1	Reset button to reset the target chip.

Table 3-18 Push Buttons

3.11 LEDs

Table 3-19 presents the LEDs.

Component	Description
Power LED	The power LED indicates that the NuMaker-M2A23SG is powered.
PF14 LED	The LED is connected to the target chip PF.14.
ICES0, ICES1, ICES2 and ICES3	Nu-Link2-Me status LED.

Table 3-19 LEDs

3.12 Nu-Link2-Me

The Nu-Link2-Me is an attached on-board debugger and programmer. The Nu-Link2-Me supports on-chip debugging, online and offline ICP programming through SWD interface. The Nu-Link2-Me also supports virtual COM port (VCOM) for printing debug messages on PC. Besides, the programming status could be shown on the built-in LEDs. Lastly, the Nu-Link2-Me could be detached from the evaluation board and become a stand-alone mass production programmer. For more information about Nu-Link2-Me, please refer to *Nu-Link2-Pro Debugger and Programmer User Manual*.

3.12.1 VCOM Switches

Table 3-20 presents how to set the VCOM function by ICESW2.

ICESW2		
Pin	Function	Description
1	TXD	On: Connect target chip PB.13 (UART0_TXD) to Nu-Link2-Me. Off: Disconnect target chip PB.13 (UART0_TXD) to Nu-Link2-Me.
2	RXD	On: Connect target chip PB.12 (UART0_RXD) to Nu-Link2-Me. Off: Disconnect target chip PB.12 (UART0_RXD) to Nu-Link2-Me.
Note: Pin 3 and 4 is unused.		

Table 3-20 VCOM Function of Nu-Link2-Me

3.12.2 Status LEDs

Table 3-19 presents the status LEDs patterns for different operation on Nu-Link2-Me.

Operation Status	Status LED			
	ICES0	ICES1	ICES2	ICES3
Boot	Flash x 3	Flash x 3	Flash x 3	Flash x 3
Idle	On	-	-	-
One Nu-Link2-Me is selected to connect	Flash x 3	Flash x 3	Flash x 3	On
ICE online (Not connected to a target chip)	On	-	Flash x 3	Flash x 3
ICE online (Connected to a target chip)	On	-	-	On
ICE online (Failed to connect to a target chip)	On	Any	Flash	On
During offline programming	-	On	-	Flash
Offline programming completed	On	-	-	-
Offline programming completed (Auto mode)	On	On	-	-
Offline programming failed	On	Flash	-	-
Note: "Online" means Nu-Link2-Me is connected to ICP Programming Tool, IDE or NuTool.				

Table 3-21 Operation Status LED Patterns

4 QUICK START

4.1 Toolchains Supporting

Install the preferred toolchain. Please make sure at least one of the toolchains has been installed.

- [KEIL MDK Nuvoton edition – Full Cortex-M](#)
- [IAR EWARM](#)
- [NuEclipse GCC \(for Windows\)](#)
- [NuEclipse GCC \(for Linux\)](#)

4.2 Nuvoton Nu-Link Driver Installation

Download and install the latest Nuvoton Nu-Link Driver.

- Download and install [Nu-Link Keil Driver](#) when using Keil MDK.
- Download and install [Nu-Link IAR Driver](#) when using IAR EWARM.
- Skip this step when using NuEclipse.

Please install the Nu-Link USB Driver as well at the end of the installation. The installation is presented in Figure 4-1 and Figure 4-2.




Figure 4-1 Nu-Link USB Driver Installation Setup




Figure 4-2 Nu-Link USB Driver Installation

4.3 BSP Firmware Download

Download and unzip the [Board Support Package \(BSP\)](#).

4.4 Hardware Setup

1. Open the virtual COM (VCOM) function by changing Nu-Link2-Me VCOM Switch No. 1 and 2 to ON.




Figure 4-3 Open VCOM Function

2. Connect the ICE USB connector shown in Figure 4-4 to the PC USB port through a USB cable.




Figure 4-4 ICE USB Connector

- Find the “Nuvoton Virtual COM Port” on the Device Manger as Figure 4-5.




Figure 4-5 Device Manager

- Open a serial port terminal, PuTTY for example, to print out debug message. Set the speed to 115200. Figure 4-6 presents the PuTTY session setting.




Figure 4-6 PuTTY Session Setting

4.5 Find the Example Project

Use the “Template” project as an example. The project can be found under the BSP folder as shown in Figure 4-7.




Figure 4-7 Template Project Folder Path

4.6 Execute the Project under Toolchains

Open and execute the project under the toolchain. The section 4.6.1, 4.6.2, and 4.6.3 describe the steps of executing project in Keil MDK, IAR EWARM and NuEclipse, respectively.

4.6.1 Keil MDK

This section provides steps to beginners on how to run a project by using Keil MDK.

1. Double-click the “Template.uvproj” to open the project.




Figure 4-8 Warning Message of “Device not found”

Note: If Figure 4-8 warning message jumps out, please migrate to version 5 format as shown in Figure 4-9. The “.uvproj” filename extension will change to “.uvprojx”.




Figure 4-9 Project File Migrate to Version 5 Format

2. Make sure the debugger is “Nuvoton Nu-Link Debugger” as shown in Figure 4-10 and Figure 4-11.




Figure 4-10 Debugger Setting in Options Window

Note: If the dropdown menu in Figure 4-10 does not contain “Nuvoton Nu-Link Debugger” item, please rework section 4.2.




Figure 4-11 Programming Setting in Options Window

3. Rebuild all target files. After successfully compiling the project, download code to the Flash memory. Click **"Start/Stop Debug Section"** button to enter debug mode.




Figure 4-12 Compile and Download the Project

4. Figure 4-13 shows the debug mode under Keil MDK. Click **"Run"** and the debug message will be printed out as shown in Figure 4-14. User can debug the project under debug mode by checking source code, assembly language, peripherals' registers, and setting breakpoint, step run, value

monitor, etc.




Figure 4-13 Keil MDK Debug Mode




Figure 4-14 Debug Message on Serial Port Terminal Windows

4.6.2 IAR EWARM

This section provides steps to beginners on how to run a project by using IAR EWARM.

1. Double click the “Template.eww” to open the project.
2. Make sure the toolbar contains “Nu-Link” item as shown in Figure 4-15.

Note: If the toolbar does not contain “Nu-Link” item, please rework section 4.2.




Figure 4-15 IAR EWARM Window

3. Make a target file as presented in Figure 4-16. After successfully compiling the project, download code to the Flash memory and enter debug mode.




Figure 4-16 Compile and Download the Project

4. Figure 4-17 shows the debug mode under IAR EWARN. Click “Go” and the debug message will be printed out as shown in Figure 4-18. User can debug the project under debug mode by checking source code, assembly language, peripherals’ registers, and setting breakpoint, step run, value monitor, etc.




Figure 4-17 IAR EWARM Debug Mode




Figure 4-18 Debug Message on Serial Port Terminal Windows

4.6.3 NuEclipse

This section provides steps to beginners on how to run a project by using NuEclipse. Please make sure the filenames and project folder path contain neither invalid character nor space.

1. Double-click "NuEclipse.exe" to open the toolchain.
2. Import the "Template" project by following the steps presented in Figure 4-19 and Figure 4-20.




Figure 4-19 Import the Project in NuEclipse




Figure 4-20 Import Projects Windows

- Click the “Template” project and find the project properties as shown in Figure 4-21. Make sure the settings are the same as settings in Figure 4-22.




Figure 4-21 Open Project Properties Window




Figure 4-22 Project Properties Settings

4. Click the “Template” project and build the project.




Figure 4-23 Build Project

5. After the project is built, click the “Template” project and set the “Debug Configuration” as shown in Figure 4-24. Follow the settings presented in Figure 4-25, Figure 4-26 and Figure 4-27 to enter debug mode.





Figure 4-24 Open Debug Configuration



Note 1: Double-click the “GDB Nuvoton Nu-Link Debugging” to create the sub item.

Note 2: After the project is built, the “*.elf” file will be shown in “C/C++ Application” frame.

Figure 4-25 Main Tab Configuration





Figure 4-26 Debugger Tab Configuration



Note: User must follow those settings highlighted in green, and configure other settings depending on the needs.

Figure 4-27 Startup Tab Configuration

6. Figure 4-28 shows the debug mode under NuEclipse. Click “**Resume**” and the debug message will be printed out as shown in Figure 4-29. User can debug the project under debug mode by checking source code, assembly language, peripherals’ registers, and setting breakpoint, step run, value monitor, etc. For more information about how to use NuEclipse, please refer to the *NuEclipse User Manual*.




Figure 4-28 NuEclipse Debug Mode




Figure 4-29 Debug Message on Serial Port Terminal Windows

5 NUMAKER-M2A23SG SCHEMATICS

5.1 Nu-Link2-Me

Figure 5-1 shows the Nu-Link2-Me circuit.




Figure 5-1 Nu-Link2-Me Circuit

5.2 M2A23 Target Board

Figure 5-2 shows the M2A23 target board circuit.




Figure 5-2 M2A23 Target Board Circuit

5.3 Extension Connectors

Figure 5-3 shows extension connectors of NuMaker-M2A23SG.




Figure 5-3 Extension Connectors Circuit

6 REVISION HISTORY

Date	Revision	Description
2025.02.20	1.00	● Initial version.

Important Notice

Nuvoton Products are neither intended nor warranted for usage in systems or equipment, any malfunction or failure of which may cause loss of human life, bodily injury or severe property damage. Such applications are deemed, "Insecure Usage".

Insecure usage includes, but is not limited to: equipment for surgical implementation, atomic energy control instruments, airplane or spaceship instruments, the control or operation of dynamic, brake or safety systems designed for vehicular use, traffic signal instruments, all types of safety devices, and other applications intended to support or sustain life.

All Insecure Usage shall be made at customer's risk, and in the event that third parties lay claims to Nuvoton as a result of customer's Insecure Usage, customer shall indemnify the damages and liabilities thus incurred by Nuvoton.

Please note that all data and specifications are subject to change without notice.
All the trademarks of products and companies mentioned in this datasheet belong to their respective owners.